

INSTALLATION INSTRUCTIONS

Xtract™ Gearbox Adapter Kit







Before Installation

- 1. Verify that thread size on provided gearbox breather adapter matches breather port.
- 2. Verify that there is clearance of at least 14 inches above reservoir breather port.
- 3. Obtain fitting that will adapt provided quick connect (or drain connector) to drain port on your reservoir.
- 4. Drain fluid from gearbox during system shutdown.
- 5. Verify that fill tube will not interfere with internal components.

Included in this Kit

- Gearbox breather adapter with fill connector
- Vacuum indicator
- Drain connector
- Desiccant breather





Installing Adapter to Gearbox

- 1. Read and follow "Before Installation" guide at beginning of this instruction sheet.
- 2. Thread vacuum indicator and fill connector into side of the adapter. Hand-tighten only.
- 3. Set assembled adapter on a clean surface.
- 4. Remove existing breather cap from gearbox.
- 5. Clean surface closely surrounding breather port.
- 6. Thread gearbox adapter into 3/4" NPT port on top surface of gearbox.
- 7. Remove red plugs from provided desiccant breather as indicated in breather installation procedures. Failure to do this will cause damage to system.
- 8. Thread desiccant breather onto top side of adapter until O-ring seals between adapter and breather surface. Hand-tighten only.

Additional Support

Lubrication Engineers may be able to provide special fittings and fasteners that will aid in installation of this product. Please contact Customer Service at 800-537-7683 with questions regarding installation or servicing of this product.



Xtract™ is a trademark of Lubrication Engineers, Inc.

LEX_GBAKII_145 08-17